Model No.: VTE180 Ultra-Slim Two Slots Charger

Your AA/AAA Battery Charger is designed to charge Vapex'Tech NiMH rechargeable batteries rated to 2700mAh (AA) or 1000mAh (AAA). You can change 1 or 2 AA/AAA NiMH batteries, or 1AA and 1 AAA batteries simultaneously.

SAVE THESE INSTRUCTIONS

CHARGER FEATURES INCLUDE:

LED Charge Indicators: The LED Lights during charging. Reverse Polarity Protection prevents the charger and batteries from damage if the batteries are incorrectly installed.

OPERATING INSTRUCTIONS:-

- Insert 1 or 2 cells AA / AAA rechargeable Ni-Cd / Ni-MH battery into the battery compartment.
- Make correct contact for polarity (+ and -); according to the sign in the battery compartment.
- Plug the charger into a correct household electric outlet. The left-hand LED indicates correct battery contact for the left shaft, and the right-hand LED for the right shaft. <u>The two LED's do</u> <u>NOT switch off when the batteries are fully charged.</u>
- Observe the charging time. Unplug and re-plug the charger each time you recharge the empty batteries.

Please use this charger in an area between 59 and 77 degree Fahrenheit (15 and 25 degree Celsius);

It is normal for batteries to become warm while charging and is no cause for alarm.

CHARGING TIME

MIGNON - R6	BY MANUAL
AA - 600 -800 mAh	5 - 7 hours
AA - 1000 -1200 mAh	8 - 10 hours
AA - 1300 -1500 mAh	10 - 12 hours
AA - 1600 -1800 mAh	12 - 14 hours
AA - 1800 -2000 mAh	14 - 16 hours
AA - 2100 -2300 mAh	16 - 18 hours
AA - 2300 -2500 mAh	18 - 20 hours
AA - 2600 -2700 mAh	20 - 22 hours
MICRO – R03	BY MANUAL
AAA – 240 -320 mAh	4.5 – 6 hours
AAA – 500 -600 mAh	9 – 11 hours
AAA – 600 -750 mAh	11 – 13.5 hours
AAA – 750 -900 mAh	13.5 – 15 hours
AAA – 1000 -1100 mAh	16 – 17 hours

CAUTION:

- 1. Before charging, read instruction.
- The supplied batteries must be recharged prior to use!
- This charger is intended for use with Nickel-Cadmium and Nickel-metal-hydride rechargeable batteries only. Attempting to charge other types of batteries may cause personal injury and damage to the charger.
- 4. Recharge only one type of battery (Ni-Cd or Ni-MH) at each time.
- 5. Do not charge longer than time specified.
- 6. Do not expose charger to rain or moisture. For indoor use only.
- 7. Remove from the mains when not in use.
- 8. The appliance is not intended for use by young children or infirm persons without supervision. Young children should be supervised to ensure that they do not play with the appliance.

BATTERY WARNING:

Charge with only standard household NiMH Battery Chargers, Do not open battery, dispose of in fire, put in backwards, mix with other battery types or short circuit--- may ignite, explode, lead or get hot, causing injury.

