



Model NO.: VTE200 Multi-Easy Charger

Your AA/AAA/PP3 Battery Charger is designed to charge Vapex'Tech NiMH rechargeable batteries rated to 2700mAh (AA) or 1000mAh (AAA) or 9VF22 (PP3) 280mAh. You can charge 2 or 4 AA/AAA NiMH batteries, or 2AA and 2 AAA NiMH batteries simultaneously. You can also charge 1 or 2 PP3 batteries.

SAVE THESE INSTRUCTIONS

CHARGER FEATURES INCLUDE:

LED Charge Indicators: The LED Lights RED during charging.

Reverse Polarity Protects the charger and batteries against damage from incorrectly installed batteries.

OPERATION INSTRUCTIONS: -

1. Insert 2 or 4 cells AA / AAA rechargeable Ni-Cd / Ni-MH battery into the battery compartment.
2. Make correct contact for polarity (+ and -); according to the sign in the battery compartment.
3. Plug the charger into a correct household electric outlet. The LED will light up instantly to indicate the proper charging.
4. Observe the charging time. Unplug and re-plug the charger each time when you recharge the empty batteries.

Please use this charger in an area between 59 and 77 degree Fahrenheit (15 and 25 degree Celsius)

It is normal for batteries to become warm while charging and is no cause for alarm.

Charging time :

Capacity of battery	Time	
AA 600-800mAh	5-6	hours
AA 1100-1300mAh	9-11	hours
AA 1400-1600mAh	11-13	hours
AA 1800-2100mAh	15-18	hours
AA 2200-2500mAh	19-21	hours
AAA 180-240mAh	4-5	hours
AAA 500-650mAh	11-15	hours
AAA 700-1000mAh	16-21	hours

Capacity of battery	Time	
9V cell 110-120mAh	9-10	hours
9V cell 150-160mAh	13-14	hours
9V cell 200mAh	17	hours
9V cell 250mAh	22	hours
9V cell 280mAh	24	hours

*Charge time will vary depending upon the brand, capacity and condition of batteries being charged.

Important Safety Instructions

5. Before charging, read instruction.
6. This charger is intended for use with Nickel-Cadmium and Nickel-metal-hydrate rechargeable batteries only. Attempting to charge other types of batteries may cause personal injury and damage to the charger.
7. Recharge only one type of battery (Ni-Cd or Ni-MH) at each time.
8. Do not charge longer than time specified. Overcharging may cause damage to the charger and battery.
9. Do not expose charger to rain or moisture. For indoor use only.
10. Remove from the mains when not in use.
11. The appliance is not intended for use by young children or infirm persons without supervision. Young children should be supervised to ensure that they do not play with the appliance.
12. Before disposing of your charger, remove the batteries from the unit and ensure it is discarded safely.

BATTERY WARNING:

Charge with only standard household NiMH Battery Chargers, Do not open battery, dispose of in fire, put in backwards, mix with other battery types or short circuit--- may ignite, explode, lead or get hot, causing injury.